


Step 1. (Figure 1)

Determine which channels you should expect to receive: Visit www.channelmaster.com/map and enter your full street address to find available channels and signal strengths at your location. Signal strength is color-coded to help guide your expectations. **GREEN** indicates the best chance to receive a channel with an indoor antenna, though interference from obstructions, nearby electronics, or LED lighting may still affect performance. **YELLOW** and **RED** indicate channels that may be less reliable and unlikely to be received with an indoor antenna.


(Fig.1)



Step 2. (Figure 2)

Connect the indoor antenna to your TV: Using the included 12 ft coaxial cable, connect the antenna to the coaxial port on your TV. (**Note:** Coaxial input port threads can vary by TV. Before threading the connector, ensure it is fully seated and aligned with the port. If it will not start threading, it is usually not seated correctly, not a defect with the connector.)


(Fig. 2)



Step 3. (Figure 3)

Find the best antenna placement & scan for channels: Place the antenna as high as possible, ideally near a window with a clear line of sight toward the broadcast towers. You may need to test several locations to find the position that provides the best reception. After each placement, run a channel scan on your TV so it can detect any channels available in that location. Avoid placing the antenna behind the TV or near electronics, as interference and movement can disrupt reception. Test multiple locations before permanently mounting. When ready to mount, **clean both the antenna surface and mounting area** to ensure the adhesive tabs bond securely. **To scan for channels:** Use your TV remote to access the TV's Settings or Menu, then choose Auto Scan or Channel Scan. Make sure the TV is set to scan for Antenna or Broadcast channels, not Cable. If Cable is selected, the TV will not find any channels.

(Fig.3)




MORE INFORMATION


Additional product information including videos and frequently asked questions is available at www.channelmaster.com/support

Warranty Information is available online at www.channelmaster.com/warranty

www.channelmaster.com



Quick Start Guide



CM-4001HDBW

PROFESSIONAL GRADE



TV ANTENNAS & ACCESSORIES

SINCE 1949

Channel Master